



inline process density and viscosity monitoring

## DENSITY AND VISCOSITY AT YOUR FINGERTIPS



WHETHER YOU'RE MEASURING GAS OR HEAVY OIL ...

... DOING PVT, EOR OR CO2 COREFLOOD ANALYSIS.

Rheonics DVM:

For high-accuracy simultaneous density and viscosity measurement up to 30,000 psi and 500 F.

WHEN YOU'RE MONITORING PROCESS DENSITY AND VISCOSITY IN FIELD CONDITIONS.



Rheonics DVP:
Rock-solid inline
process density and
viscosity measurement
for pipes, tanks and
process systems.

Rheonics SRV: Wide range viscosity control. Equally at home in Newtonian and non-Newtonian fluids, slurries, gels, dispersions and pastes.



learn more at: www.rheonics.com info@rheonics.com

Invented, designed and built with Swiss precision.